


VST 50





EXPLODED PARTS LIST


Year: 2021

Page(s): 2/6

VST 50

No	Code	Name	Qty	No	Code	Name	Qty
1	064505	spring	1	49	051902	self-tapping screw ST4.2*16	2
2		D pin 6x40	2	50		belt lever	1
3		wheel hub	2	51	070440	belt 10X660	1
4	022384	trye 13x4.10-6	2				
5		bolt M8X20	6				
6	051890	B pin 1.5x25	2				
7		bolt M8x1	1				
8		adjusting nut	1				
9	051870	upper handle,right	1				
10		connecting rod	1				
11		bolt M8X40	6				
12		washer 8x22x2	6				
13	051881	hex lock nut M8	9				
14		upper handle,left	1				
15	064498	walking cable	1				
16		elastic washer	2				
17		hex lock nut M6	5				
18	050121	handle bar	2				
19		handle bolt	2				
20		control lever,right	1				
21	050071	handle waher	2				
22	064488	auger wire	1				
23	064469	control lever,left	1				
24	056104	bolt M8X45	2				
25		panel	1				
26		pre-tension spring	1				
27		hex bolt M8X35	1				
28		wire pin	1				
29	050104	control lever	1				
30		plastic clip 8	2				
31	064499	belt cover	1				
32	051865	chute handle	1				
33		plastic nut	2				
34		pin	1				
35	051866	chute cap sealed cover	1				
36	051847	chute cap assembly	1				
37		bolt M6X16	2				
38	051848	chute assembly	1				
39		safty fence	1				
40	051873	cap 6	1				
41		plastic washer	1				
42		fence washer	1				
43	051867	connecting disc	1				
44	050087	chute fixed seating 1	1				
45	051868	leaf spring	1				
46	056183	shovel	1				
47	050174	chute fixed seating	1				
48		bolt M6X20	3				

VST 50





EXPLODED PARTS LIST


Year: 2021

Page(s): 4/6

VST 50

No	Code	Name	Qty	No	Code	Name	Qty
1		hex bolt M10x25	1	49		support plate	1
2		big washer 10	1	50		bolt M6x25	1
3	051872	belt pulley	1	51		single thrust bearing 51104	1
4	038225	flat key A6x6x14	1	52		ball bearing 6004	1
5	51881	jam nut M8	17	53	050060	seal ring FB20x35x7	1
6	064470	bearing seat	1	54		bushing	1
7		small tension pulley	1	55		scrapper	1
8		washer for tension pulley	1	56		bolt M8x20	4
9	051882	bearing 6004	1	57		hexagon locking-nuts with flange M8	4
10		big tension plate	1	58	050175	fixing seat for chute	1
11	051898	bolt M8x30	1				
12	056167	shovel seat	1				
13	051902	screw ST4.2x9.5-F	2				
14	064497	housing assembly	1				
15		hex screw M8x16	6				
16		bolt M8x16	11+4				
17	041837	skid shoe plastic	2				
18		big washer 8	4				
19	041886	skid shoe steel (optional)	2				
20	050125	fan	1				
21		Inner Hexagonal Bolt M6X35	2				
22	051881	jam nut M6	3				
23	064485	worm shaft	1				
24		cushion	1				
25	038225	flat key 5x5x35	1				
26	064489	worm head	1				
27		ball bearing 6001	1				
28	038217	worm case left	1				
29		bolt combination M6x20	5				
30	038218	paper washer	1				
31	050089	bearing inner seat	2				
32		ball bearing 6203	2				
33	050124	bearing seat	2				
34	038220	left auger	1				
35	038221	output shaft	1				
36	050136	safety bolt	2				
37	038223	B pin	2				
38	038224	drive shaft sleeve	4				
39	038225	round head flat key 6x18	1				
40	038226	seal ring FB19x30	2				
41		washer	2				
42		screw M6x16	2				
43	038227	right auger	1				
44	056107	wave washer 13	1				
45	038228	worm	1				
46		oil cup	1				
47	050074	output shaft sleeve Ø19	2				
48		worm case right	1				

VST 50





EXPLODED PARTS LIST

Year: 2021

Page(s): 6/6

VST 50

No	Code	Name	Qty	No	Code	Name	Qty
1	064484	transmission case	1	49		small tension pulley	1
2	064472	shifting fork	1	50		small tension plate	1
3		small shaft sleeve	2	51	051898	hex bolt M8x30	1
4	51890	B pin Ø1.5x25	3	52	064505	small tension spring	1
5		pin shaft B 8x35	1	53		hex bolt M8x35	4
6	064506	driving shaft	1	54		hex nut M8	4
7	064507	driving gear	1	55		engine	1
8	064508	shaft sleeve	2				
9		shaft washer	2				
10	051883	circlip A 20	2				
11	051881	hex screw M8	3				
12	051873	plastic clip 8	2				
13		steel cover	1				
14		bearing 6200N	2				
15	038241	gear	1				
16	051874	bolt M6x16	3				
17	064509	rubber pulley	1				
18	064486	ring seat	1				
19	038238	shift bearing	1				
20	051876	circlip 25	1				
21	064473	sexi-shaft	1				
22	064498	walking cable	1				
23		hex bolt M5X35	2				
24		hex nut M5	2				
25		reset spring	1				
26		seat for friction disc	1				
27	051886	flat washer C 10	1				
28		spring washer 10	1				
29		hex nut M12	1				
30		hex nut M6	3				
31		stepped screw M6	2				
32		washer	1				
33		bearing 6204-2LS	1				
34		screw M6x12	6				
35	064474	cover for friction disc	1				
36	064475	transmission shaft	1				
37	064476	friction disc	1				
38		stepped nut M8	1				
39		hex bolt M8X16	1				
40		hex screw M6X20	1				
41		check ring	1				
42		hex nut M6	3				
43	064477	small pulley	1				
44		screw M8x8	1				
45		synchronous belt 5M710-15	1				
46		flat key 4.7x4.7x60	1				
47		small synchronous pulley	1				
48		hex nut M8	1				